



SLR-20L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001564	MAIN BODY	703	17030019	WORM SHAFT GUARD
101	11010028	BODY LOGO	704	17040035	WORM GUIDE SUPPORT BAR
102	11020015	BODY FOOT	705	17050020	TRANSMISSION GEAR
103	11030003	BODY FOOT SCREW	707	17070010	TRANSMISSION GEAR
104	11040001	BODY FOOT NUT	708	17080007	TRANSMISSION GEAR
105	11050018	WORM SHAFT BUSHING	709	17090014	TRANSMISSION GEAR BUSHING
105-1	11050009	WORM SHAFT BUSHING	709-1	17090015	TRANSMISSION GEAR BUSHING
108	11080019	HANGER	710	17100034	LINE GUIDE ASSY
108-1	11080017	HANGER	712	17120059	WORM SHAFT
108-2	11080030	THE PROTECTION COVER OF REELS LUGS	713	17130002	LINE GUIDE PAWL CAP
114	11140005	CLAMP	715	17150001	LINE GUIDE PAWL
115	11150006	WING SCREW	717	17170004	MAIN SHAFT PIN
116	11160003	WING NUT	718	17180210	MAIN SHAFT
117	11170002	RETAINER NUT	723	17230009	SILENT SPRING
200	12001780	MAIN SIDE PLATE	913	19130002	SPRING WASHER
201	12010027	ANTLRE PAWL	19000004	19000004	E RETAINER
203	12030004	CONTROL PIN	29000002	29000002	E RETAINER
204	12040002	COMPRESSION SPRING	29000001	29000001	E RETAINER
205	12050033	DECORATION PLATE	19010006	19010006	C RETAINER
206	12060002	LEVER DRAG STOPPER CAP	0910460	0910460	BALL BEARING
207	12070076	HOLDED PLATE	0910099	0910099	BALL BEARING
208	12080082	SIDE PLATE COVER	0910179	0910179	BALL BEARING
215	12150022	HOLD PLATE BUSHING	0910445	0910445	BALL BEARING
215-1	12150023	HOLD PLATE BUSHING	0910459	0910459	BALL BEARING
217	12170014	ANTLRE PAWL SPRING	09201000	09201000	WASHER
217-1	12170018	ANTLRE PAWL SPRING	0920490	0920490	WASHER
300	13000963	VICE SIDE PLATE	0920480	0920480	WASHER
303	13030068	CLICK KNOB	0920319	0920319	WASHER
304	13040019	CLICK PAWL	0920218	0920218	WASHER
305	13050014	CLICK PAWL SPRING	0920207	0920207	WASHER
311	13110079	SIDE PLATE COVERS	0920510	0920510	WASHER
400	14000848	SPOOL	0920426	0920426	WASHER
401	14010036	CLICK GEAR	0920154	0920154	WASHER
402	14020011	LINE HOLDER	0920503	0920503	WASHER
404	14040011	PRESSURE LOAD BLOCK	0920506	0920506	WASHER
405	14050031	SPOOL COVER	0920068	0920068	WASHER
406	14060006	BUSHING	0920004	0920004	WASHER
500	15000347	HANDLE ASSY.	0920453	0920453	WASHER
501	15010013	HANDLE NUT	0920481	0920481	WASHER
507	15070032	PUSH BUTTON	0920263	0920263	WASHER
513	15130025	HANDLE COVER	0920282	0920282	WASHER
516	15160030	HANDLE NUT RETAINER	09301130	09301130	SCREW
600	16000101	CAST CONTROL CAP	0930651	0930651	SCREW
601	16010004	DRAG NUT	09301052	09301052	SCREW
602	16020049	ADJUST BLOCK	0930196	0930196	SCREW
605	16050131	LEVER DRAG ASSY	0930668	0930668	SCREW
607	16070053	PINION GUARD	09301256	09301256	SCREW
608	16080004	DRAG WASHER RETAINER	0930129	0930129	SCREW
609	16090012	SPRING WASHER	0930044	0930044	SCREW
611	16110050	EARED WASHER	0930614	0930614	SCREW
612	16120064	KEY WASHER	0930646	0930646	SCREW
613	16130007	COMPRESSION SPRING	0930211	0930211	SCREW
700	17000096	DRIVE GEAR	09301115	09301115	SCREW
701	17010263	DRIVE GEAR SHAFT	0930048	0930048	SCREW
702	17020056	PINION GEAR	0940056	0940056	O RING