



CJ-400P PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41004481	MAIN BODY ASSY	711	47110041	GUIDE SLIDE BASE ASSY
105	41050002	WORM SHAFT BUSHING	712	47120005	WORM SHAFT
117	11170020	RETAINER NUT	713	47130001	LINE GUIDE PAWL CAP
200	42000344	HANDLE SIDE PLATE ASSY	715	17150009	LINE GUIDE PAWL
201	42010001	ANTI-RE PAWL	720	17200003	DRIVE GEAR SHAFT BUSHING
202	42020007	RATCH	721	47210001	DRIVE GEAR SHAFT BUSHING
206	42060003	STOPPER CAP	801	48010002	CLUTCH SHAFT SPRING
211	42110001	ANTI-RE PAWL PIN	803	48030006	CLUTCH BAR SUPPORT
220	42200007	SIDE PLATE HOLDED SCREW	804	48040018	CLUTCH SLIDER ASSY
222	42220005	MAIN SIDE PLATE HOLDER	805	48050002	PINION GEAR YOKE
226	42260001	CONTROL PIN	806	48060001	YOKE SPRING
300	43000581	VICE SIDE PLATE	807	48070001	YOKE BRAKED PLATE
302	43020017	WASHER	808	48080002	YOKE BRAKED PLATE SPRING
303	43030019	CLICK BUTTON	809	48090002	CLUTCH BAR WASHER
400	44000457	SPOOL ASSY.	810	48100002	CLUTCH SHAFT BUSHING
401	14010030	CLICK GEAR	812	48120001	BRAKED PLATE HOLDER
401	44010001	SPOOL CLICK GEAR	813	48130016	CLUTCH BAR CAP
500	45000147	HANDLE ASSY.	29000002	29000002	E RETAINER
515	15150008	HANDLE SCREW	29000001	29000001	E RETAINER
600	46000059	CAST CONTROL CAP ASSY	0910207	0910207	BALL BEARING
608	46080003	DRAG WASHER RETAINER	0910365	0910365	BALL BEARING
608-1	46080002	DRAG WASHER RETAINER	0910153	0910153	BALL BEARING
609	16090009	DRAG SPRING WASHER	0910005	0910005	BALL BEARING
610	16100055	DRAG WASHER	0910024	0910024	BALL BEARING
610-1	16100037	DRAG WASHER	0920105	0920105	WASHER
611	16110006	EARED WASHER	0920118	0920118	WASHER
612	16120028	KEY WASHER	0920081	0920081	WASHER
612-1	16120027	KEY WASHER	0920133	0920133	WASHER
612-2	26120056	KEY WASHER	0920477	0920477	WASHER
612-3	16120026	KEY WASHER	0920076	0920076	WASHER
615	46150130	STAR DARG ASSY	0920066	0920066	WASHER
700	47000005	DRIVE GEAR	0920326	0920326	WASHER
701	47010004	DRIVE GEAR SHAFT	0920448	0920448	WASHER
702	47020059	PINION GEAR	0930684	0930684	SCREW
703	47030011	WORM SHAFT GUARD	0930131	0930131	SCREW
704	47040011	LINE GUIDE SUPPORT BAR	0930429	0930429	SCREW
705	47050007	TRANSMISSION GEAR	0930700	0930700	SCREW
708	47080003	TRANSMISSION GEAR	0940027	0940027	O RING
709	47090006	TRANSMISSION GEAR BUSHING	0940020	0940020	O RING