



Vi-200R PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41004431	MAIN BODY	705	47050008	TRANSMISSION GEAR
105	41050003	WORM SHAFT BUSHING	705-1	47050009	TRANSMISSION GEAR
117	41170001	RETAINER NUT	711	47110032	GUIDE SLIDE BASE ASSY.
119	41190032	BODY COVER	712	47120007	WORM SHAFT
200	42000228	HANDLE SIDE PLATE	713	47130003	LINE GUIDE PAWL CAP
202	42020002	RATCH	715	47150002	LINE GUIDE PAWL
206	42060003	STOPPER CAP	720	47200004	DRIVE GEAR SHAFT BUSHING
226	42260001	CONTROL PIN	721	47210002	DRIVE GEAR SHAFT BUSHING
300	43000151	VICE SIDE PLATE	721-1	47210003	DRIVE GEAR SHAFT BUSHING
302	43020004	WASHER	725	47250001	TRANSMISSION GEAR PIN
316	43160013	FIXED PLATE BUTTON ASSY	800	48000005	CLUTCH SHAFT
316-1	43160020	FIXED PLATE BUTTON	801	48010004	CLUTCH SHAFT SPRING
400	44000716	SPOOL ASSY.	802	48020068	CLUTCH PLATE
401	44010008	CLICK GEAR	804	48040004	CLUTCH SLIDER
412	24120038	SPOOL BUSHING	804-1	48040008	CLUTCH SLIDER
500	45000086	HANDLE ARM ASSY.	805	48050007	PINION GEAR YOKE
516	45160024	HANDLE NUT RETAINER	806	48060002	YOKE SPRING
600	46000050	CAST CONTROL CAP	806-1	48060004	YOKE SPRING
608	46080002	DRAG WASHER RETAINER	807	48070006	YOKE BRAKED PLATE
609	16090009	DRAG SPRING WASHER	808	48080004	YOKE BRAKED PLATE SPRING
610	16100018	DRAG WASHER	812	48120003	BRAKED PLATE HOLDER
610-1	16100037	DRAG WASHER	900	29000001	E RETAINER
610-2	16100038	DRAG WASHER	910	0910170	BALL BEARING
611	16110006	EARED WASHER	920	0920105	WASHER
612	16120027	KEY WASHER	920	0920292	WASHER
612-1	16120028	KEY WASHER	920	0920329	WASHER
612-2	26120056	KEY WASHER	930	0930011	SCREW
615	46150051	STAR DRAG	930	0930547	SCREW
619	46190003	WASHER	930	0930763	SCREW
700	47000019	DRIVE GEAR	930	0930704	SCREW
701	47010009	DRIVE GEAR SHAFT	930	0930044	SCREW
702	47020030	PINION GEAR	930	0930982	SCREW
703	47030017	WORM SHAFT GUARD	940	0940003	O RING
704	47040012	LINE GUIDE SUPPORT BAR			