



#### Helios 3/4 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000003	Body assy. (with main shaft)	408	34080013	Spool reatiner
102	31020135	Reel foot	409	34090007	Spool reatiner spring
104	31040023	Spool holder knob	410	34100053	Spool cover assy.
207	32070003	Handle knob spacer	413	34130015	Counter balance
300	33000089	Drag knob	416	34160007	Bearing bushing
300-1	33000084	Drag knob	900	29000002	E type retainer
304	33040027	Click pawl assy.	910	0910093	One way bearing assy.
310	33100017	Cork drag washer	910	0910090	Ball bearing
310-1	33100033	Drag washer	920	0920006	Washer
310-2	33100020	Cork drag washer	920	0920127	Washer
312	33120004	Glaze Key washer	920	0920368	Washer
312-1	33120005	Key washer	930	0930086	Screw
314	33140002	Spring washer	930	0930098	Screw
321	33210012	Drive gear disk break	930	0930115	Screw
327	33270003	Drag knob bushing	930	0930897	Screw
340	33400003	Drag washer retainer	940	0940007	O ring
400	34000681	Spool assy.	940	0940009	O ring
400-1	34000625	Spool	940	0940013	O ring
404	34040023	Handle knob	940	0940022	O ring
405	34050012	Handle knob rivet	940	0940025	O ring

07/12/2011

309OKM02701031