




IS-250 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41004459	MAIN BODY ASSY	712	47120009	WORM SHAFT
105	41050002	WORM SHAFT BUSHING	713	47130001	LINE GUIDE PAWL CAP
117	41170008	RETAINER NUT	715	17150009	LINE GUIDE PAWL
200	42000337	HANDLE SIDE PLATE ASSY	720	17200003	DRIVE GEAR SHAFT BUSHING
201	42010001	ANTI-RE PAWL	721	47210001	DRIVE GEAR SHAFT BUSHING
202	42020007	RATCH	801	48010002	CLUTCH SHAFT SPRING
206	42060003	STOPPER CAP	803	48030004	CLUTCH BAR SUPPORT
211	42110001	ANTI-RE PAWL PIN	804	48040018	CLUTCH SLIDER ASSY
220	42200007	SIDE PLATE HOLDED SCREW	805	48050002	PINION GEAR YOKE
222	42220005	MAIN SIDE PLATE HOLDER	806	48060001	YOKE SPRING
226	42260001	CONTROL PIN	807	48070001	YOKE BRAKED PLATE
300	43000579	VICE SIDE PLATE	808	48080002	YOKE BRAKED PLATE SPRING
302	43020017	WASHER	809	48090002	CLUTCH BAR WASHER
400	44000756	SPOOL ASSY.	810	48100002	CLUTCH SHAFT BUSHING
401-2	14010030	CLICK GEAR	812	48120001	BRAKED PLATE HOLDER
500	45000142	HANDLE ASSY.	813	48130016	CLUTCH BAR CAP
516	45160033	HANDLE NUT RETAINER	29000002	29000002	E RETAINER
600	46000059	CAST CONTROL CAP ASSY	29000001	29000001	E RETAINER
608	46080003	DRAG WASHER RETAINER	0910207	0910207	BALL BEARING
609	16090009	DRAG SPRING WASHER	0910365	0910365	BALL BEARING
610	16100055	DRAG WASHER	0910153	0910153	BALL BEARING
610-1	16100037	DRAG WASHER	0910024	0910024	BALL BEARING
611	16110006	EARED WASHER	0920105	0920105	WASHER
612	16120028	KEY WASHER	0920118	0920118	WASHER
612-1	16120027	KEY WASHER	0920081	0920081	WASHER
612-2	26120056	KEY WASHER	0920477	0920477	WASHER
612-3	16120026	KEY WASHER	0920076	0920076	WASHER
615	46150130	STAR DARG ASSY	0920066	0920066	WASHER
700	47000005	DRIVE GEAR	0920448	0920448	WASHER
701	47010004	DRIVE GEAR SHAFT	0920326	0920326	WASHER
702	47020059	PINION GEAR	09301202	09301202	SCREW
703	47030009	WORM SHAFT GUARD	0930684	0930684	SCREW
704	47040008	LINE GUIDE SUPPORT BAR	0930131	0930131	SCREW
705	47050007	TRANSMISSION GEAR	0930429	0930429	SCREW
708	47080003	TRANSMISSION GEAR	0930700	0930700	SCREW
709	47090001	TRANSMISSION GEAR BUSHING	0940020	0940020	O RING
711	47110041	GUIDE SLIDE BASE ASSY	0940027	0940027	O RING