




TORMENTA

TT-266W



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	5K134707	Palm Side Cover Assembly	39	5K155801	Bearing
2	5K134801	Lock Pin	40	5K027001	Washer
3	6K974401	Coil Spring	41	6K181101	Washer
4	5K102301	Magnet Holder Assembly	42	6K181202	Tension Nut
5	5K047001	Tap Screw	43	6K311306	Screw
6	5K027001	Washer	44	6K256901	Bearing
7	6K758901	Bearing	45	63201402	Retainer
8	6K468301	Ring	46	5K134901	Bearing Plate
9	5K134407	Spool Assembly	47	6K398604	Screw
10	6K311311	Screw	48	5K093603	Gear Metal
11	6K311306	Screw	49	6K258101	Gear
12	6K314101	Screw	50	6K893602	Ratchet
13	6B339801	Retainer	51	5K027101	Washer
14	6K456801	Bush	52	5K131301	Drive Gear
15	6K931104	Level Wind Assembly	53	5K039901	Washer-L
16	6K256501	Level Wind Pin	54	5K040001	Washer-D
17	6K148801	Washer	55	6K859201	Sleeve
18	6K704403	Level Wind Nut	56	6K177302	Washer
19	6K456403	Pipe	57	6K582201	Ball Bearing
20	6K095602	Worm Shaft	58	6K177302	Washer
21	6E096503	Washer	59	6K259201	Leaf Spring Assembly
22	6K469301	Worm Pinion	60	5K027201	Spring Washer
23	6B339801	Retainer	61	6K193601	Washer
24	5K130801	Hood	62	5K133804	Star Drag Assembly
25	6K930401	Pillar	63	6K161404	Leaf Spring
26	5K132803	Frame Assembly	64	5K135305	Handle Assembly
27	6K977206	Thumb Bar Assembly	65	6K178309	Handle Nut
28	5K119001	Kick Lever Spring	66	6K311004	Handle Nut Cap
29	5K130601	Kick Lever	67	63511805	Screw
30	5K093401	Clutch Cam Spring	68	5K132406	Control Dial
31	5K130701	Clutch Cam	69	6K974701	Leaf Spring
32	6K723502	Screw	70	6K180201	O-Ring
33	6K723502	Screw	71	5K132701	Slide Cam-B
34	5K093701	Clutch	72	5K100501	Coil Spring
35	6K942501	Coil Spring	73	5K096201	Slide Cam-A
36	5K153801	Pinion	74	5K124901	Spool Cover
37	5K131511	Gear Side Cover Assembly	75	5K047001	Screw
38	6K176501	O-Ring	76	6E096503	Washer