


Model : SR-200W

okuma
BAITCAST REEL

SERRANO
SR-200W



Key No.	Part No.	Part Name
1	5K0950013	PALM SIDE COVER
2	6K9745012	LOCK PIN
3	6K9744010	COIL SPRING
4	5K0951011	SPOOL COVER ASSY
5	635359020	TAP SCREW
6	5K0270010	SPOOL TENSION WASHER-A
7	6K474501N	BALL BEARING
8	6K4683010	RING
9	5K0946032	SPOOL ASSY
10	6K3113110	SCREW-A
11	6K9562030	SCREW-B
12	6K3141011	TAP SCREW
13	632059010	RETAINER
14	5K0285010	BUSH
15	6K6264010	BALL BEARING
16	6K4686011	PIPE
17	5K0929011	LEVEL WIND ASSY
18	5K0418020	LEVEL WIND PIN
19	6K1488010	WASHER
20	6K7044030	NUT
21	5K0932010	WORM SHAFT
22	6K6264010	BALL BEARING
23	5K0285010	BUSH
24	6K1618061	WASHER
25	6K4693010	WORM PINION
26	6B3398010	RETAINER
27	5K0942031	HOOD
28	6K9304011	PILLAR
29	5K0926013	FRAME ASSY

30	6K9772050	THUMB BAR ASSY
31	5K1190010	KICK LEVER SPRING
32	5K0928010	KICK LEVER
33	5K0934011	CLUTCH CAM SPRING
34	5K0933011	CLUTCH CAM
35	6K7235020	CLUTCH CAM SCREW
36	6K7235020	CLUTCH CAM SCREW
37	5K0937010	CLUTCH
38	6K9425010	COIL SPRING
39	5K0938012	PINION
40	5K0943010	G/SIDE COVER ASSY
41	6K9049010	O-RING
42	6K1767010	BALL BEARING
43	5K0270010	SPOOL TENSION WASHER-A
44	6K1769052	COLLAR
45	6K1770010	CUSHION WASHER
46	5K0953040	TENSION KNOB
47	6K3113110	SCREW-A
48	6K1706010	BALL BEARING
49	632014020	RETAINER
50	6K9299010	BEARING PLATE
51	6K3986040	SCREW
52	5K0936020	GEAR METAL
53	6K2581010	GEAR
54	6K8936021	RATCHET
55	6K1745040	WASHER-L1
56	5K0939021	DRIVE GEAR
57	5K0940010	WASHER-L2
58	6K9431010	WASHER-D1
59	5K0941010	WASHER-A
60	6K9431030	WASHER-D2
61	6K8824020	COLLAR
62	6K8967011	SLEEVE
63	6K1773010	WASHER
64	6K2592013	LEAF SPRING ASSY
65	5K0272010	SPRING WASHER
66	6K1936010	WASHER
67	5K0840061	STAR DRAG ASSY
68	6K1614040	LEAF SPRING
69	5K0957050	HANDLE ASSY
70	5K0471051	HANDLE NUT
71	5K0050040	HANDLE NUT RETAINER
72	635204080	SCREW

Model : SR-200

9	5K0954021	SPOOL ASSY
40	5K0943030	G/SIDE COVER ASSY