




Key No.	Part No.	Part Name
1	5K177631	PALM SIDE COVER
2	5K134801	LOCK PIN
3	6K974402	COIL SPRING
4	5K181201	SPOOL COVER ASSEMBLY
5	6AK21802	SCREW
6	6K164605	WASHER
7	6K474507	BALL BEARING
8	6K468301	RING
9	5K281603	SPOOL ASSEMBLY (1 BALL BEARING)
10	6K704403	NUT
11	6K148801	WASHER
12	6K256501	LEVEL WIND PIN
13	6B339801	RETAINER
14	5K028501	BUSH
15	5K238001	LEVEL WIND ASSEMBLY
16	6K626404	BALL BEARING
17	6K468601	PIPE
18	5K093203	WORM SHAFT
19	5K028501	BUSH
20	6K161806	WASHER
21	6K469301	WORM PINION
22	6B339801	RETAINER
23	5K177315	HOOD
24	6K314102	SCREW
25	6K930403	PILLAR
26	6K311306	SCREW
27	6K311311	SCREW
28	5K181137	FRAME ASSEMBLY
29	5K138303	THUMB BAR ASSEMBLY
30	5K138201	SPRING
31	5K177501	KICK LEVER
32	5K138401	SPRING
33	5K177401	CLUTCH CAM
34	6K723502	SCREW
35	6K723502	SCREW
36	5K133401	CLUTCH
37	5K382101	COIL SPRING
38	5K131104	PINION
39	6K170701	RING
40	6K304004	BALL BEARING
41	5K177134	GEAR SIDE COVER ASSEMBLY

Key No.	Part No.	Part Name
42	6K904901	O-RING
43	5K201601	COIL SPRING
44	5K201501	CLICK PIN
45	5K201401	CLICK PLATE
46	6K394501	RETAINER
47	6K311306	SCREW
48	6K170604	BALL BEARING
49	63201402	RETAINER
50	5K134901	BEARING PLATE
52	6K398604	SCREW
53	5K093617	GEAR METAL
54	6K258101	GEAR
55	6K893602	RATCHET
56	5K027101	WASHER
57	5K180509	DRIVE GEAR
59	6K943101	WASHER-D
60	5K094003	WASHER-L
61	5K094101	WASHER-A
62	6K943103	WASHER-D
63	6K896721	SLEEVE
64	6K177302	WASHER
65	6K259201	LEAF SPRING ASSEMBLY
66	5K027201	SPRING WASHER
67	5K174201	DU-WASHER
68	5K0840D8	STAR DRAG ASSEMBLY
69	5K199101	WASHER
70	5K231515	HANDLE ARM ASSEMBLY
72	5K129201	WASHER
73	5K231207	HANDLE KNOB ASSEMBLY
74	63511816	SCREW
75	5K154621	HANDLE KNOB CAP
77	5K181817	NUT
78	5K005001	RETAINER
79	63520406	SCREW
80	5K201301	RING
81	5K201201	CONTROL PLATE
82	5K319601	TENSION SHAFT
83	6K709201	WASHER
84	5K201010	TENSION KNOB
85	5K403508	TENSION KNOB ASSEMBLY
86	6K177301	WASHER