


FSP101-A/FSP101H-A



NO.	Parts Name	Parts NO.		NO.	Parts Name	Parts NO.		NO.	Parts Name	Parts NO.
100	frame	97110092		138	spring	97110053		500	handle arm	97110138
101	gear side cover	97110097/97110098		140	handle nut cap	97110125		600	handle knob	97110139
102	palm side cover	97110105		141	handle nut	97110126		601	handle knob cap	97110142
103	front cover	97110109		142	jump ring	97050002		603	handle shaft	97110082
106	decorative cover	97110113		200	control dial	97110128		1	handle assy	97110146
107	stopper lever plate	97110012		201	control dial spring	97050004		2	side cover assy	97110151
108	stopper lever	97110014		202	slider a	97110059		3	spool assy	97110155
109	drive gear	97110016/97110017		203	slider b	97110060		T1	bush	97110083
110	gear metal	97110020		204	magnet holder	97110061		T2	bush	97110084
111	bearing plate	97110022		205	magnet plate	97110062		T3	bush	97110156
112	clutch gear	97110023/97110024		206	magnet	97110063		T4	bush	97110157
113	ratchet wheel	97110027		207	spool cover	97110064		T5	bush	97110158
114	o/way clutch	97010001		208	jump ring	97050003		E1	washer	97020007
115	line guide	97110028		209	spring	97110058		E2	washer	97020008
116	line wind	97110029		210	rubber	97020001		E4	O ring	97040001
117	worm shaft	97110030		218	sound spring	97110065		E5	washer	97020009
118	line wind pin	97110031		300	spool	97110131		E6	washer	97020010
119	pillar	97110032		301	main shaft	97110067		B1	bearing	97010002
120	pin	97110033		302	main shaft pin	97110068		B2	bearing	97010003
121	pipe	97110034		400	button	97110134		B4	bearing	97010005
122	line wind nut	97110035		401	rubber	97110070		S1	screw	97030001
123	e-ring	97050001		403	sonud sheet	97110071		S2	screw	97030002
125	drive gear	97110036		404	jump ring	97110072		S3	screw	97030003
126	w-pinion gear	97110037		405	star drag	97110137		S4	screw	97030004
127	thumb bar	97110121		409	washer	97020002		S7	screw	97030005
129	clutch cam	97110039		410	d-washer	97020003		S8	screw	97030006
130	clutch shaft	97110041		412	washer	97020004		S12	screw	97030007
131	clutch cam plate	97110043		413	washer	97020005				
132	kick lever	97110045		416	sound sheet	97020006				
133	kick lever plate	97110047		417	star drag nut	97110075				
135	torsion spring	97110049		418	spring	97110076				
136	clutch	97110051		419	stell ball	97110077				