


SRN100-A/SRN100H-A



NO.	Parts Name	Parts NO.	NO.	Parts Name	Parts NO.
100	frame	97110002	138	spring	97110053
101	gear side cover	97110005/97110006	140	handle nut cap	97110055
102	palm side cover	97110008	141	handle nut	97110056
103	front cover	97110010	142	jump ring	97050002
106	decorative cover	97110011	200	control dial	97110057
107	stopper lever plate	97110013	201	control dial spring	97050004
108	stopper lever	97110015	202	slider a	97110059
109	drive gear	97110018/97110019	203	slider b	97110060
110	gear metal	97110021	204	magnet holder	97110061
111	bearing plate	97110022	205	magnet plate	97110062
112	clutch gear	97110025/97110026	206	magnet	97110063
113	ratchet wheel	97110027	207	spool cover	97110064
114	o/way clutch	97010001	208	jump ring	97050003
115	line guide	97110028	209	spring	97110058
116	line wind	97110029	210	rubber	97020001
117	worm shaft	97110030	218	sound spring	97110065
118	line wind pin	97110031	300	spool	97110066
119	pillar	97110032	301	main shaft	97110067
120	pin	97110033	302	main shaft pin	97110068
121	pipe	97110034	400	button	97110069
122	line wind nut	97110035	401	rubber	97110070
123	e-ring	97050001	403	sound sheet	97110071
125	drive gear	97110036	404	jump ring	97110072
126	w-pinion gear	97110037	405	star drag	97110074
127	thumb bar	97110038	409	washer	97020002
129	clutch cam	97110040	410	d-washer	97020003
130	clutch shaft	97110042	412	washer	97020004
131	clutch cam plate	97110044	413	washer	97020005
132	kick lever	97110046	416	sound sheet	97020006
133	kick lever plate	97110048	417	star drag nut	97110075
135	torsion spring	97110050	418	spring	97110076
136	clutch	97110052	419	stell ball	97110077