


SRN101-A/SRN101H-A



NO.	Parts Name	Parts NO.	NO.	Parts Name	Parts NO.	Parts NO.	NO.	Parts Name	Parts NO.
100	frame	97110001	138	spring	97110053	500	handle arm	97110078	
101	gear side cover	97110003/97110004	140	handle nut cap	97110054	600	handle knob	97110079	
102	palm side cover	97110007	141	handle nut	97110056	601	handle knob cap	97110080	
103	front cover	97110009	142	jump ring	97050002	602	handle knob inside	97110081	
106	decorative cover	97110011	200	control dial	97110057	603	handle shaft	97110082	
107	stopper lever plate	97110012	201	control dial spring	97050004	1	handle assy	97110086	
108	stopper lever	97110014	202	slider a	97110059	2	side cover assy	97110087	
109	drive gear	97110016/97110017	203	slider b	97110060	3	spool assy	97110085	
110	gear metal	97110020	204	magnet holder	97110061	T1	bush	97110083	
111	bearing plate	97110022	205	magnet plate	97110062	T2	bush	97110084	
112	clutch gear	97110023/97110024	206	magnet	97110063	E1	washer	97020007	
113	ratchet wheel	97110027	207	spool cover	97110064	E2	washer	97020008	
114	o/way clutch	97010001	208	jump ring	97050003	E4	O ring	97040001	
115	line guide	97110028	209	spring	97110058	E5	washer	97020009	
116	line wind	97110029	210	rubber	97020001	E6	washer	97020010	
117	worm shaft	97110030	218	sound spring	97110065	B1	bearing	97010002	
118	line wind pin	97110031	300	spool	97110066	B2	bearing	97010003	
119	pillar	97110032	301	main shaft	97110067	B3	bearing	97010004	
120	pin	97110033	302	main shaft pin	97110068	B4	bearing	97010005	
121	pipe	97110034	400	button	97110069	B5	bearing	97010006	
122	line wind nut	97110035	401	rubber	97110070	B6	bearing	97010007	
123	e-ring	97050001	403	sonud sheet	97110071	S1	screw	97030001	
125	drive gear	97110036	404	jump ring	97110072	S2	screw	97030002	
126	w-pinion gear	97110037	405	star drag	97110073	S3	screw	97030003	
127	thumb bar	97110038	409	washer	97020002	S4	screw	97030004	
129	clutch cam	97110039	410	d-washer	97020003	S7	screw	97030005	
130	clutch shaft	97110041	412	washer	97020004	S8	screw	97030006	
131	clutch cam plate	97110043	413	washer	97020005	S12	screw	97030007	
132	kick lever	97110045	416	sound sheet	97020006				
133	kick lever plate	97110047	417	star drag nut	97110075				
135	torsion spring	97110049	418	spring	97110076				
136	clutch	97110051	419	stell ball	97110077				