


C101-A/C101H-A



NO.	Parts Name	Parts NO.		NO.	Parts Name	Parts NO.		NO.	Parts Name	Parts NO.
100	frame	97110089		138	spring	97110053		500	handle arm	97110078
101	gear side cover	97110003/97110004		140	handle nut cap	97110054		600	handle knob	97110140
102	palm side cover	97110104		141	handle nut	97110056		601	handle knob cap	97110080
103	front cover	97110009		142	jump ring	97050002		602	handle knob inside	97110081
106	decorative cover	97110118		200	control dial	97110057		603	handle shaft	97110082
107	stopper lever plate	97110012		201	control dial spring	97050004		1	handle assy	97110144
108	stopper lever	97110014		202	slider a	97110059		2	side cover assy	97110148
109	drive gear	97110016/97110017		203	slider b	97110060		3	spool assy	97110153
110	gear metal	97110020		204	magnet holder	97110061		T1	bush	97110083
111	bearing plate	97110022		205	magnet plate	97110062		T2	bush	97110084
112	clutch gear	97110023/97110024		206	magnet	97110063		T3	bush	97110156
113	ratchet wheel	97110027		207	spool cover	97110064		E1	washer	97020007
114	o/way clutch	97010001		208	jump ring	97050003		E2	washer	97020008
115	line guide	97110028		209	spring	97110058		E4	o ring	97040001
116	line wind	97110029		210	rubber	97020001		E5	washer	97020009
117	worm shaft	97110030		218	sound spring	97110065		E6	washer	97020010
118	line wind pin	97110031		300	spool	97110130		B1	bearing	97010002
119	pillar	97110032		301	main shaft	97110067		B2	bearing	97010003
120	pin	97110033		302	main shaft pin	97110068		B3	bearing	97010007
121	pipe	97110034		400	button	97110133		B4	bearing	97010005
122	line wind nut	97110035		401	rubber	97110070		B5	bearing	97010004
123	e-ring	97050001		403	sonud sheet	97110071		S1	screw	97030001
125	drive gear	97110036		404	jump ring	97110072		S2	screw	97030002
126	w-pinion gear	97110037		405	star drag	97110073		S3	screw	97030003
127	thumb bar	97110038		409	washer	97020002		S4	screw	97030004
129	clutch cam	97110039		410	d-washer	97020003		S7	screw	97030005
130	clutch shaft	97110041		412	washer	97020004		S8	screw	97030006
131	clutch cam plate	97110043		413	washer	97020005		S12	screw	97030007
132	kick lever	97110045		416	sound sheet	97020006				
133	kick lever plate	97110047		417	star drag nut	97110075				
135	torsion spring	97110049		418	spring	97110076				
136	clutch	97110051		419	stell ball	97110077				