


MSV-100A/MSV-100HA



NO.	Parts Name	Parts NO.	NO.	Parts Name	Parts NO.	NO.	Parts Name	Parts NO.
100	frame	97110282	138	spring	97110053	418	spring	97110076
101	gear side cover	97110283	140	handle nut cap	97110288	419	stell ball	97110077
102	palm side cover	97110284	141	handle nut	97110289	500	handle arm	97110297
103	front cover	97110285	142	jump ring	97050002	600	handle knob	97110298
106	decorative cover	97110286	200	control dial	97110290	601	handle knob cap	97110299
107	stopper lever plate	97110013	201	control dial spring	97050004	602	handle knob inside	97110300
108	stopper lever	97110015	202	slider a	97110059	603	handle knob inside	97110300
109	drive gear	97110018/97110019	203	slider b	97110060	1	handle assy	97110302
110	gear metal	97110021	204	magnet holder	97110061	2	side cover assy	97110303
111	bearing plate	97110022	205	magnet plate	97110062	3	spool assy	97110304
112	clutch gear	97110025/97110026	206	magnet	97110063	T1	bush	97110083
113	ratchet wheel	97110027	207	spool cover	97110064	T2	bush	97110084
114	o/way clutch	97010001	208	jump ring	97050003	T3	bush	97110156
115	line guide	97110028	209	spring	97110058	E1	washer	97020007
116	line wind	97110029	210	rubber	97020001	E2	washer	97020008
117	worm shaft	97110030	218	sound spring	97110065	E3	washer	97020022
118	line wind pin	97110031	300	spool	97110291	E4	o ring	97040001
119	pillar	97110032	301	main shaft	97110292	E5	washer	97020009
120	pin	97110033	302	main shaft pin	97110293	E6	washer	97020010
121	pipe	97110034	400	button	97110294	B1	bearing	97010002
122	line wind nut	97110035	401	rubber	97110070	B2	bearing	97010003
123	e-ring	97050001	403	sonud sheet	97110071	B3	bearing	97010007
125	drive gear	97110036	404	jump ring	97110072	B4	bearing	97010005
126	w-pinion gear	97110037	405	star drag	97110295	B5	bearing	97010004
127	thumb bar	97110287	409	washer	97020002	S1	screw	97030008
129	clutch cam	97110040	410-1	d-washer	97020018	S2	screw	97030009
130	clutch shaft	97110042	410-2	d-washer	97020023	S3	screw	97030010
131	clutch cam plate	97110044	411	washer	97020019	S4	screw	97030011
132	kick lever	97110046	412	washer	97020020	S6	screw	97030016
133	kick lever plate	97110048	413	washer	97020021	S7	screw	97030012
135	torsion spring	97110050	416	sound sheet	97020006	S8	screw	97030013
136	clutch	97110052	417	star drag nut	97110296	S12	screw	97030014